



Andreas Gärtner
Werkzeugtechnik GmbH
Marie-Curie-Straße 35
30974 Wennigsen

Fon: 05103/8083
Fax: 05103/8084

eMail: info@ag-iwt.de
www.ag-iwt.de

Toleranzfelder Einheitswelle

Toleranzen	Nennmaß in mm												
	über	bis	über	bis	über	bis	über	bis					
	0	3	3	6	6	10	10	18	18	30	30	50	50
Angaben in µm													
P9	-6	-12	-15	-18	-22	-26	-32						
	-31	-40	-51	-61	-74	-88	-106						
H6	+6	+8	+9	+11	+13	+16	+19						
	0	0	0	0	0	0	0						
H7	+10	+12	+15	+18	+21	+25	+30						
	0	0	0	0	0	0	0						
H8	+14	+18	+22	+27	+33	+39	+46						
	0	0	0	0	0	0	0						
H9	+25	+30	+36	+43	+52	+62	+74						
	0	0	0	0	0	0	0						
H10	+40	+48	+58	+70	+84	+100	+120						
	0	0	0	0	0	0	0						
H11	+60	+75	+90	+110	+130	+160	+190						
	0	0	0	0	0	0	0						
H12	+100	+120	+150	+180	+210	+250	+300						
	0	0	0	0	0	0	0						
H13	+140	+180	+220	+270	+330	+390	+460						
	0	0	0	0	0	0	0						